

头戴无线耳机

MZ-307



用户手册


产品参数

咪头尺寸: ϕ 6.0mm	电池容量: 600mAh
采样率: 48KHZ	充电时长: 2.5H
频率范围: 32Ω	工作时长: 8H
频率响应: 2.402-2.476GHZ	收发距离: ≥10m
喇叭阻抗: 20HZ~20KHZ	产品尺寸: 183*204*98mm
喇叭直径: ϕ 40mm	产品净重: 285g

包装清单




佩戴耳机



- 将标有 L 的一侧耳机戴在左耳, 将标有 R 的一侧耳机戴在右耳。
- 可伸缩头梁, 确保佩戴舒适。
- 根据需要调整麦克风。

产品概述



- 01** 音量+/下一曲
 - 当在播放模式下, 短按下一曲, 长按音量加, 最大音量时会报“嘟嘟”提示音
- 02** 麦克风静音开关
 - 短按为麦克风静音; 在蓝牙/2.4G状态下, 长按进入蓝牙/2.4G配对状态; 短按两次为开/关RGB炫彩灯
- 03** 音量-/上一曲
 - 当在播放模式下, 短按上一曲, 长按音量减, 最小音量时会报“嘟嘟”提示音
- 04** 电源开关
 - 向上滑动电源开关, 开启耳机; 向下滑动电源开关, 关闭耳机
- 05** RGB炫彩灯
- 06** 3.5mm音频插孔
- 07** USB充电口
- 08** LED 指示灯 (电源/蓝牙/ 2.4G)

功能介绍


- 充电提示**
 - 电池低于3.4V, 耳机会报“No battery, please charge”提示音, 表示目前处于低电状态, 需要对耳机进行充电。
- 指示灯**
 - 耳机开机, 在搜索回连状态下, 蓝灯闪烁。
 - 耳机开机, 短按麦克风静音键“”, 麦克风静音红灯亮起, 取消麦克风静音蓝灯亮起; 长按麦克风静音键“”3秒, 进入配对状态, 蓝灯快闪。
 - 耳机开机, 在连接成功状态下, 蓝灯常亮。
 - 耳机开机, 在断开连接状态下, 蓝灯慢闪。
 - 耳机开/关机, 在充电状态下, 红灯常亮, 充满红灯熄灭。

- 自动关机**
 - 耳机开机, 10分钟后没有配对成功, 耳机会自动关机。
 - 耳机与蓝牙/2.4G配对成功状态下, 10分钟无音频输出, 耳机会自动关机。
 - 电池低于3.4V, 耳机会报“No battery, please charge”提示音, 两分钟后自动关机。

耳机连接


3.5mm音频线连接

1. 将音频线接头连接到耳机。
2. 将音频线另一个接头连接到 PC、Mac、移动设备或游戏控制台设备上的3.5mm耳机插孔。



2.4G无线连接

1. 将USB Dongle插入PC、Mac或PS4上的USB接口且与耳机蓝牙模式连接过的设备的蓝牙没有处于打开状态。
2. 打开耳机, 耳机将自动配对并连接到USB Dongle。
配对成功后耳机蓝灯常亮, USB接收器蓝牙常亮, 耳机会报“嘟嘟”提示音。



3. 2.4G模式切换到蓝牙模式:
 - 耳机开机后没有与USB Dongle连接时, 即可与蓝牙设备配对连接。
 - 耳机与USB Dongle连接状态时, 拔掉USB Dongle, 断开与USB Dongle的连接, 蓝灯慢闪, 即可与蓝牙设备配对连接。

蓝牙连接

1. 打开耳机, 蓝灯快闪, 耳机进入搜索状态且此时USB Dongle没有插入USB接口, 即没有处于工作状态。
2. 手机打开蓝牙, 搜索名称“MZ-307”并进行配对, 配对成功耳机蓝灯常亮。



3. 耳机与手机连接状态下处于播放状态时, 短按麦克风静音键“”, 可实现播放/暂停功能。
4. 蓝牙模式切换到2.4G模式:
 - 耳机开机后没有与手机蓝牙连接时, 即可与USB Dongle配对连接。
 - 耳机与手机蓝牙连接状态时, 长按麦克风静音键“”3秒断开与手机蓝牙的连接, 蓝灯慢闪, 即可与USB Dongle配对连接。

保养与维护

- 勿将本产品放在过冷或者潮湿的地方, 以免影响产品内部电路; 需避免在激烈运动或出汗较多时使用本产品, 防止汗水渗透到产品内部损坏本产品。
- 勿将本产品放置在太阳直射或者温度高的地方。高温会缩短电子部件的使用寿命、损坏电池、使某些塑料部件变形。
- 勿试图拆开本产品。如果非专业人员, 可能会损坏本产品。
- 不要跌落、强烈振动、用硬体撞击本产品, 以免会损坏产品内部电路。
- 勿使用烈性化学制品、清洁剂清洁本产品。
- 不要用尖体在本产品表面上乱划, 以免损坏外壳和影响外观。

注意事项

- 为保证您的人身安全, 请勿将本产品佩戴或放置在离心机搅拌器过近的位置。
- 儿童应在成人监督下使用本产品, 本产品并非玩具。
- 在高音量下使用本产品, 特别是长时间使用, 可能会对您的听力造成损伤。
- 如果您产生了热感或听不到声音, 请立即取下本产品并断开连接。
- 为交通安全起见, 驾驶时或骑自行车时请勿使用本产品。

故障排除

无法打开耳机

- 耳机在无活动10分钟后将自动关闭。请再次打开耳机。
- 给电池充电。

耳机未与移动设备连接

- 在移动设备上, 关闭蓝牙功能并重新打开。然后尝试重新配对。
- 从移动设备的蓝牙列表删除“MZ-327”。然后尝试重新配对。
- 将移动设备靠近耳机, 远离其他干扰或障碍物。
- 尝试对另一种移动设备进行配对。

没有声音

- 确保耳机已开启且电池有电。
- 确保耳机和移动设备(或音乐应用)已加大音量。
- 尝试对另一种移动设备进行配对。
- 尝试使用其他音乐程序。
- 如果已主动连接了两个移动设备, 首先要确保其他装置已经暂停。

音质差

- 将移动设备置于耳机附近, 远离任何干扰。
- 尝试对另一种移动设备进行配对。

Wearing Wireless Headset

MZ-307




User Manual

Product parameters


Microphone size: Φ 6.0mm	Battery capacity: 600mAh
Sampling rate: 48KHZ	Frequency Response: 2.402-2.476GHZ
Frequency range: 32Ω	Speaker impedance: 20HZ~20KHZ
Charging time: 2.5h	Send and receive distance: ≥10M
Working time: 8h	Product size: 183*204*98MM
Horn diameter: Φ 40mm	Product Weight:285g

Packing list




Headset 3.5mm audio cable USB Dongle Manual

Wearing headphones



- ☑Put the side marked L on the left ear and the side marked R on the right ear.
- ☑Retractable head beam for a comfortable fit.
- ☑Adjust the microphone as needed.

Product description



- 01 + Volume+/Next track**
☑When in play mode, short press a song, long press volume up, a beep sound will be reported when the volume is at maximum
- 02 🎧 Microphone mute switch**
☑Short press to mute the microphone; in the Bluetooth/2.4G state, long press to enter the Bluetooth/2.4G pairing state; short press twice to turn on/off the RGB colorful lights
- 03 — Volume-/Previous track**
☑When in play mode, short press the previous song, long press the volume to decrease, and a "beep" sound will be reported when the volume is at minimum
- 04 ⏻ Switch**
☑Slide the power switch up to turn on the headset; slide the power switch down to turn off the headset
- 05** RGB colorful lights **06** 3.5mm audio jack
07 USB charging port **08** LED Indicator (Power/Bluetooth/2.4G)

Features

Charging Tips

- ☑When the battery is lower than 3.4V, the earphone will report a prompt sound of "No battery, please charge", indicating that the battery is currently in a low power state and the earphone needs to be charged.

Indicator light

- ☑The headset is turned on, and the blue light flashes in the search and reconnect state.
- ☑Turn on the headset, short press the microphone mute button "🎧", the microphone mute red light is on, and the microphone mute blue light is on; long press the microphone mute button "🎧" for 3 seconds to enter the pairing state, and the blue light flashes quickly.
- ☑The headset is turned on, and the blue light is always on when the connection is successful.
- ☑When the headset is turned on, the blue light flashes slowly in the disconnected state.
- ☑When the headset is turned on/off, in charging state, the red light is always on, and the red light is off when fully charged.


Automatic shut-down

- ☑Turn on the headset, if the pairing is not successful after 10 minutes, the headset will automatically shut down.
- ☑When the headset is successfully paired with Bluetooth/2.4G, if there is no audio output for 10 minutes, the headset will automatically shut down.
- ☑When the battery is lower than 3.4V, the earphone will report "No battery, please charge" and automatically shut down after two minutes.

Headphone connection


3.5mm audio cable connection

1. Connect the audio cable connector to the headset.
2. Connect the other connector of the audio cable to the 3.5mm headphone jack on your PC, Mac, mobile or game console device.



2.4G wireless connection


1. Insert the USB Dongle into the USB port on the PC, Mac or PS4 and the Bluetooth of the device that has been connected to the headset Bluetooth mode is not turned on.
2. Turn on the headset, the headset will automatically pair and connect to the USB Dongle. After the pairing is successful, the blue light of the headset is always on, the Bluetooth of the USB receiver is always on, and the headset will report a "beep" sound.



3. Switch from 2.4G mode to Bluetooth mode:
 - ☑If the headset is not connected to the USB Dongle after it is turned on, it can be paired and connected with a Bluetooth device.
 - ☑When the headset is connected to the USB Dongle, unplug the USB Dongle, disconnect the connection with the USB Dongle, the blue light flashes slowly, and you can pair and connect with the Bluetooth device.

Bluetooth connection

1. Turn on the headset, the blue light flashes quickly, the headset enters the search state and the USB Dongle is not plugged into the USB port at this time, that is, it is not in working state.
2. Turn on the Bluetooth of the mobile phone, search for the name "MZ-307" and pair it. The blue light of the headset is always on when the pairing is successful.



3. When the headset is connected to the mobile phone and is playing, short press the microphone mute button "🎧" to realize the play/pause function.
4. Switch the Bluetooth mode to 2.4G mode:
 - ☑When the headset is not connected to the mobile phone via Bluetooth after it is turned on, it can be paired with the USB Dongle.
 - ☑When the headset is connected to the mobile phone via Bluetooth, long press the microphone mute button "🎧" for 3 seconds to disconnect the Bluetooth connection with the mobile phone, the blue light flashes slowly, and the USB Dongle can be paired and connected.

Care and Maintenance

- ☑Do not place this product in a place that is too cold or humid, so as not to affect the internal circuit of the product; avoid using this product during vigorous exercise or sweating a lot to prevent perspiration from penetrating into the product and damaging the product.
- ☑Do not place this product in a place exposed to sunlight or high temperature. High temperatures can shorten the life of electronic components, damage batteries, and deform certain plastic parts.
- ☑Do not attempt to disassemble this product. Non-professionals may damage this product.
- ☑Do not drop, vibrate strongly, or hit the product with hard objects, so as not to damage the internal circuit of the product.
- ☑Do not use strong chemicals, cleaning agents to clean this product.
- ☑Do not scratch the surface of this product with a sharp point to avoid damage to the case and appearance.

Precautions

- ☑For your personal safety, do not wear or place this product too close to a pacemaker.
- ☑Children should use this product under adult supervision, this product is not a toy.
- ☑Using this product at high volume, especially for a long time, may damage your hearing.
- ☑If you experience heat or hear no sound, remove and disconnect the product immediately.
- ☑For traffic safety, do not use this product while driving or riding a bicycle.

Troubleshooting

Can't turn on headset

- ☑The headset will automatically turn off after 10 minutes of inactivity. Please turn on the headset again.
- ☑Charge the battery.

The headset is not connected to the mobile device

- ☑On mobile devices, turn off the Bluetooth function and turn it back on. Then try pairing again.
- ☑Remove "MZ-307" from the mobile device's Bluetooth list. Then try pairing again.
- ☑Move your mobile device close to the headset, away from other distractions or obstacles.
- ☑Try pairing with another mobile device.

No sound

- ☑Make sure the headset is turned on and the battery is charged.
- ☑Make sure your headphones and mobile device (or music app) are turned up.
- ☑Try another music program.
- ☑Try pairing with another mobile device.
- ☑If two mobile devices are actively connected, first make sure the other devices are suspended.

Poor sound quality

- ☑Keep your mobile device close to the headset and away from any distractions.
- ☑Try pairing with another mobile device.